

WireLuxe, WireLace Bracelet**Materials needed:**Available at SonoranBeads.com:

- 9" WireLuxe Laguna #3702Laguna
- 1yd 12mm - WireLace Pale Silver #1662
- 1pr - 20mm Ribbon Crimps #3587 Silver color
- 1 - Starry Night Clasp - #3293 Silver

From your stash:

- 2 - 3mm jump rings

Tools Needed:

- 2 - Chain nose pliers
- Scissors - for cutting WireLace™
- Wire Cutters

**Sonoran Beads****Step-by-step instructions:**

1. Cut the WireLuxe™ to the desired length taking into consideration that the clasp will add one inch to the overall length. Trim any wires that might be sticking out.
2. Cover one end of the WireLace™ with a little piece of tape in order to help ease it through the WireLuxe™.
3. Starting at about ¼ inch from the end of the WireLuxe™ separate the wires in the center section by pulling them apart with your fingers or a dull tool. From the underside of the WireLuxe™ bring the WireLace™ up through the gap.
4. Separate the wires in the center section about every ½ inch and weave the WireLace™ in and out of the WireLuxe™ until you reach the end.
5. Pull the WireLace™ out of the end a bit and cut off the tape on the end. Cover each end with a ribbon crimp, capturing both the WireLuxe™ and WireLace™. Repeat on the other end.
6. Attach the clasp with the jump rings. Enjoy!

Olive WireLuxe™ and Grass WireLace™